# Compte Rendu TP : Configuration de Samba + Unix

#### 1. Introduction

Ce compte rendu présente les étapes de configuration d'un partage de fichiers à l'aide de Samba sur un système Unix/Linux. L'objectif est de permettre l'accès aux fichiers partagés à partir d'autres machines, notamment sous Linux.

## 2. Préreguis

- Un système Unix/Linux installé (ex : Ubuntu)
- Droits administrateur (sudo)
- Accès à Internet pour l'installation des paquets

### 3. Installation de Samba

Commande pour installer Samba:

sudo apt install samba

```
unix@ubuntu:~$ sudo apt update
[sudo] password for unix:
Hit:1 http://security.ubuntu.com/ubuntu focal-security InRelease
Hit:2 http://us.archive.ubuntu.com/ubuntu focal InRelease
Hit:3 http://us.archive.ubuntu.com/ubuntu focal-updates InRelease
Hit:4 http://us.archive.ubuntu.com/ubuntu focal-backports InRelease
Reading package lists... Done
Building dependency tree
Reading state information... Done
All packages are up to date.
unix@ubuntu:~$ sudo apt upgrade
Reading package lists... Done
Building dependency tree
Reading state information... Done
C Terminal ng upgrade... Done
0 upgraded, 0 newly installed, 0 to remove and 0 not upgraded.
unix@ubuntu:~$ sudo apt install samba -y
Reading package lists... Done
Building dependency tree
Reading state information... Done
The following additional packages will be installed:
```

Vérification du statut du service Samba:

### sudo systemctl status smbd

# 4. Configuration du Partage

Création d'un dossier public à partager :

```
sudo mkdir -p /srv/samba/partage
sudo chmod 777 /srv/samba/partage
```

```
unix@unix-VirtualBox:~$ sudo mkdir -p /srv/samba/partage
unix@unix-VirtualBox:~$ sudo chmod 777 /srv/samba/partage
```

Modification du fichier de configuration :

sudo nano /etc/samba/smb.conf

```
GNU nano 4.8

browseable = no
path = /var/spool/samba
printable = yes
guest ok = no
read only = yes
create mask = 0700

# Windows clients look for this share name as a source of downloadable
# printer drivers

[prints]

comment = Printer Drivers
path = /var/lib/samba/printers
browseable = yes
read only = yes
guest ok = no

# Uncomment to allow remote administration of Windows print drivers.

# You may need to replace 'lpadmin' with the name of the group your
# admin users are members of.
# Please note that you also need to set appropriate Unix permissions
# to the drivers directory for these users to have write rights in it

[partage]
path = /srv/samba/partage
read only = no
guest ok = yes
```

Redémarrer Samba pour appliquer la configuration :

```
sudo systemctl restart smbd
```

## 5. Partie Client Linux

Installation de smbclient :

sudo apt update sudo apt install smbclient

```
unix@unix-VirtualBox:~$ sudo apt install smbclient

Reading package lists... Done

Building dependency tree

Reading state information... Done

The following packages were automatically installed and are no longer required:

linux-headers-5.15.0-67-generic linux-hwe-5.15-headers-5.15.0-67

linux-image-5.15.0-67-generic linux-modules-5.15.0-67-generic
```

Connexion au partage en mode invité :

smbclient //IP\_SERVEUR/partage -U guest

# 6. Partage Protégé par Mot de Passe

Création d'un utilisateur Samba:

sudo adduser sambauser sudo smbpasswd -a sambauser

```
unix@unix-VirtualBox:~$ sudo adduser wassim
Adding user `wassim' ...
Adding new group `wassim' (1001) ...
Adding new user `wassim' (1001) with group `wassim' ...
Creating home directory `/home/wassim' ...
Copying files from `/etc/skel' ...
New password:
Retype new password:
passwd: password updated successfully
Changing the user information for wassim
Enter the new value, or press ENTER for the default
    Full Name []: wassim
    Room Number []: karouia
    Work Phone []: 23607384
    Home Phone []:
    Other []:
Is the information correct? [Y/n] y
unix@unix-VirtualBox:~$
```

```
unix@unix-VirtualBox:~$ sudo smbpasswd -a wassim
New SMB password:
Retype new SMB password:
Added user wassim.
```

Creation d'un dossier Privé:

sudo mkdir -p /srv/samba/prive sudo chown sambauser:sambauser /srv/samba/prive sudo chmod -R 777 /srv/samba/prive

```
unix@unix-VirtualBox:~$ sudo mkdir -p /srv/samba/privet
unix@unix-VirtualBox:~$ sudo chown wassim:wassim /srv/samba/privet
unix@unix-VirtualBox:~$ sudo chmod -R 777 /srv/samba/privet
```

Ajouter la configuration correspondante dans smb.conf.

```
[privet]
path= /srv/samba/privet
valid users = wassim
read only = no
```

## 7. Vérification

Créer un fichier depuis le client et vérifier sa présence sur le serveur.

```
unix@unix-VirtualBox:~$ sudo mkdir -p /srv/samba/privet
unix@unix-VirtualBox:~$ sudo chown wassim:wassim /srv/samba/privet
unix@unix-VirtualBox:~$ sudo chmod -R 777 /srv/samba/privet
```

```
unix@unix-VirtualBox:~$ echo " hello wassim " > test.txt
unix@unix-VirtualBox:~$ smbclient //192.168.1.2/privet -U wassim
Password for [WORKGROUP\wassim]:
Try "help" to get a list of possible commands.
smb: \> put test.txt
putting file test.txt as \test.txt (3.7 kb/s) (average 3.7 kb/s)
smb: \> ls
                                     D
                                              0 Tue Apr 29 21:08:33 2025
                                              0 Tue Apr 29 21:03:24 2025
                                     D
                                             15 Tue Apr 29 21:08:33 2025
  test.txt
                                     Α
               25107716 blocks of size 1024. 13553960 blocks available
smb: \>
```

```
unix@unix-VirtualBox:~$ ls /srv/samba/privet
test.txt
unix@unix-VirtualBox:~$ cd /srv/samba/privet
unix@unix-VirtualBox:/srv/samba/privet$ cat test.txt
hello wassim
```

## 8. Conclusion

Ce TP a permis de comprendre la mise en place d'un partage de fichiers avec Samba et de tester le fonctionnement côté client Linux avec et sans authentification.